

DC17 QUICK REFERENCE CARD

FILE

ICON	NAME	SHORTCUT
	New	Ctrl + N
	Open	Ctrl + O
	Save	Ctrl + S
	Output to disk	Not applicable
	Cut	Ctrl + X
	Copy	Ctrl + C
	Paste	Ctrl + V
	Merge Designs	Alt + F, M
	Print	Ctrl + P
	Print Preview	Not applicable
	Print Setup	Not applicable

SELECT

ICON	NAME	SHORTCUT
	Select	S
	Lasso Select	Not applicable
	Guideline select	Not applicable

STITCH EDIT

ICON	NAME	SHORTCUT
	Stitch Select	M
	Lasso Stitch Select	Not applicable
	Delete Stitch	Not applicable

DESIGN EDIT

ICON	NAME	SHORTCUT
	Set Design Start /End	Not applicable

PATH EDIT

ICON	NAME	SHORTCUT
	Angle Lines	D
	Slice Lines	U
	Density Line	Not applicable
	Stitch Length	Not applicable
	Variable width	Not applicable
	Wave	Not applicable

SLICE

ICON	NAME	SHORTCUT
	Slice	C
	Curved Slice	Not applicable
	Rectangle Slice	Not applicable
	Freeform Slice	Not applicable

NODE EDIT

ICON	NAME	SHORTCUT
	Vertex Select	N
	Edit Envelope	Not applicable
	Copy Partial Path	Not applicable
	Rounded Corner Tool	Not applicable
	Drag Anchor Path	Not applicable
	Average Anchor Vertically	Not applicable

ICON	NAME	SHORTCUT
	Average Anchor Horizontally	Not applicable
	Lasso anchor select	Not applicable

MEASURE

ICON	NAME	SHORTCUT
	Measure	Ctrl + M

ZOOM

ICON	NAME	SHORTCUT
	Zoom	Z
	Back to 1:1	1
	Fit to Window	2
	Fit Selection to Window	4

OUTLINE

ICON	NAME	SHORTCUT
	Connect Shapes	Ctrl + Shift + O
	Reduce Nodes	Not applicable
	Remove Fill Color	Not applicable

ARTWORK

ICON	NAME	SHORTCUT
	Pen	P
	Rectangle	Not applicable
	Ellipse	Not applicable
	Autotrace	Not applicable

DRAW FUSION

ICON	NAME	SHORTCUT
	Open Draw Fusion	Not applicable

IMPORT

ICON	NAME	SHORTCUT
	Load image	Not applicable
	Import Artwork	Not applicable
	Import TrueType®	Not applicable

LETTERING

ICON	NAME	SHORTCUT
	Text	Not applicable
	Stepped	Not applicable
	Arc	Not applicable
	Circle	Not applicable
	Three-letter Monogram	Not applicable
	Line Angle	Not applicable
	Vertical	Not applicable
	Rainbow Text	Not applicable

SETTINGS PAINTER

ICON	NAME	SHORTCUT
	Copy Settings	Shift + C
	Paste Settings	Shift + V

STANDARD DIGITIZING

ICON	NAME	SHORTCUT
	Enhanced Column	F12
	Column	Ctrl + F8
	Manual	F5
	Run	F6
	Complex Fill	F11
	Steil	F7
	Satin Path	F9
	Complex Satin	Not applicable

SPECIALIZED DIGITIZING

ICON	NAME	SHORTCUT
	Cross-stitch	Not applicable
	Cross-stitch Fill	Not applicable
	Cascade Fill	Not applicable
	Fur Stitch	Not applicable
	Star	Not applicable
	Radial Fill	Not applicable
	Spiral Fill	Not applicable
	Appliqué	Not applicable
	Appliqué Cut	Not applicable
	Line Carving	Shift. + F10
	Region Carving	Ctrl + F10
	Symbol	Shift + F9
	Manual Sequin	Not applicable

ICON	NAME	SHORTCUT
	Shape Echo	Not applicable
	Complex Modifier	Not applicable
	Brush Tool	
	Rickrack	
	Focus Fill	
	Sun Stitch	

STEPS

ICON	NAME	SHORTCUT
	Undo	Ctrl + Z
	Redo	Ctrl + Y
	Repeat	Shift + Rs

PERSONALIZATION

ICON	NAME	SHORTCUT
	WordIt	Not applicable
	ColorIt	Not applicable
	Random Repeat	Not applicable
	Import Emoji	Not applicable

MACHINE

ICON	NAME	SHORTCUT
	Output to Machine	Not applicable
	Design Queue	Not applicable
	Machine Status	Not applicable
	View Reports	Not applicable

DESIGN TOOLS

ICON	NAME	SHORTCUT
	Segment Filter	Not applicable
	Hide Selected Segment(s)	Shift + H
	Hide Unselected Segment(s)	Ctrl + H
	Show all Hidden Segments	Ctrl + Shift + H
	Show Commands	Not applicable
	Show/Hide Dots	Shift + P
	Show/Hide Beads	Ctrl + B
	Show/Hide Stitches	X
	Show/Hide Outlines	Shift + X
	Show Active Group (Stitches in Outline Mode)	Shift + A
	Show/Hide Grid	Not applicable
	Snap To Menu	Not applicable
	Show Repeats	Not applicable
	View by color	V
	Show/Hide Draw Ribbon	Not applicable
	Show/Hide 3D Stitches	3
	Move Forward by 1	Ctrl + →
	Move Forward by 10	Ctrl + Insert
	Mover Forward by 100	Ctrl + ↑
	Mover Forward by 1000	Ctrl + "+" (keypad)
	Move by Command	Not applicable
	Move by Color	Not applicable
	Move to End	Ctrl + End

ICON	NAME	SHORTCUT
	Range Select	Not applicable
	Convert	=

ARTWORK TAB - EDIT TOOLS

ICON	NAME	SHORTCUT
	Duplicate	Ctrl + D
	Power Copy	Ctrl + W
	Circular Copy	Not applicable
	Power Edit	W
	Offset	Shift + O
	Resize	Ctrl + R
	Rotate	Ctrl + T
	Reflect	Ctrl + F

ARTWORK TAB - SHAPE TOOLS

ICON	NAME	SHORTCUT
	Combine	Ctrl + L
	Breakup	Ctrl + K

SEGMENT TAB

ICON	NAME	SHORTCUT
	Set Entry Exit Point	O
	Insert Before	Insert
	Insert After	Ctrl+Insert
	Bring to End of Design	Shift + End
	Bring to Start of Design	Shift + Home

ICON	NAME	SHORTCUT
	Move Later by 1	Shift + Page Up
	Move Earlier by 1	Shift + Page Down

	Group	Ctrl + G
	Ungroup	Ctrl + U

IMAGE TAB

ICON	NAME	SHORTCUT
	Show/Hide image	I
	Lighten image	L
	Backdrop selectT	Ctrl + I

AUTO TAB

ICON	NAME	SHORTCUT
	Auto Breakup	Shift + J
	Auto Start/Stop	L
	Smart Join mode	Ctrl + I

GENERATION TAB

ICON	NAME	SHORTCUT
	Auto Breakup	Shift + J
	Auto Start/Stop	L

COMMAND

ICON	NAME	SHORTCUT
	Insert Trim at End	F9
	End Lock	Not applicable

VIEWING COMMANDS

COMMAND	SHORTCUT
Sequence View	Shift + T
Zoom in on pointer	Press + on the number keypad
Zoom out	Press - on the number keypad
Highlight Stitch Exceptions	Alt + X
Move Guidelines	Press Ctrl + Shift while left-clicking on the guideline
Handles On/Off	Ctrl + Q

DRAWING MODES

MODE	SHORTCUT
Bezier	B
Bezier to cusp	Ctrl
Arc	A
Freehand	F
Circle	R
Quickdraw	Q
Autotrace	T
Curve	Right-click

DIGITIZING COMMANDS

COMMAND	SHORTCUT
Go Back	Backspace
Force Horizontal	F2
Force vertical	Shift + F2
Connect	F3
Snap to Grid	Shift + 3
Snap to Anchor Points	F3
Snap to Guidelines	Shift+F4
Snap to Artwork	F4
Close Shape	O
Activate Bean Stitch Tool	Shift + F6
Draw lines at 15-degree Increments	Press Shift while digitizing or editing
Outline Select/Stitch Select (toggle)	Spacebar

COMMAND	SHORTCUT
Activate Manual Jump Stitches	Press and hold Ctrl while digitizing a Manual segment
Close Segment	Enter
Branching	K
Join s	J

EDITING COMMANDS

COMMAND	SHORTCUT
Display Shortcut Menu	Ctrl + E
Delete	Delete
Move to Previous Command	Ctrl + /
Move to Next Command	Ctrl + * (keypad)
Group Selection	Shift + left-click last stitch or segment in group
One by One Group Selection	Ctrl + left-click each stitch or segment
Expand Group Selection	Ctrl + Shift + left-click additional stitches or segments
Copy Angle Line	Press Ctrl while dragging angle line

Notes:

Tajima DG17 is available in different system levels. Upgrading to a higher level means that more tools and commands are available.

This card lists tools and commands available with Maestro (the highest system level). Depending on the system level you have, you may not have some of the tools and commands listed.



www.tajimasoftware.com



www.tajima.com

© Copyright 2024 Tajima Software Solutions LLC. All rights reserved.